


安裝方式選項 MOTOR MOUNTING SELECTIONS:

● D-直結式

D-Direct fixed type

1. 馬達軸心鍵與減速機入力軸鍵槽對齊置入。
2. 馬達與減速機結合後將馬達上4根螺絲鎖緊即可。

1. Place motor shaft key and reducer input shaft key way in a straight line, and insert motor shaft into reducer input shaft.
2. After connection of motor and reducer, tighten four screws into hex-socket cap screw holes.



● S-止付式

S-Set screw fixed type

1. 馬達軸心鍵與減速機入力軸鍵槽對齊置入。
2. 馬達與減速機結合後將馬達上4根螺絲鎖緊。
3. 使用T型扳手將減速機入力軸內的止付螺絲鎖緊即可。

1. Place motor shaft key and reducer input shaft key way in a straight line, and insert motor shaft into reducer input shaft.
2. After connection of motor and reducer, tighten four screws into hex-socket cap screw holes.
3. Fix the set screw on reducer input shaft by T-type spanner.

