


安裝方式選項 MOTOR MOUNTING SELECTIONS:

● S-止付式

S-Set screw fixed type

- 1.馬達軸心鍵與減速機入力軸鍵槽對齊置入。
- 2.馬達與減速機結合後將馬達上4根螺絲鎖緊。
- 3.使用T 型板手將減速機入力軸內的止付螺絲鎖緊即可。

- 1.Place motor shaft key and reducer input shaft key way in a straight line, and insert motor shaft into reducer input shaft.
- 2.After connection of motor and reducer, tighten four screws into hex-socket cap screw holes.
- 3.Fix the set screw on reducer input shaft by T-type spanner.



● L-束緊式:

L-Clamp fixed type

- 1.馬達軸心鍵與減速機入力軸鍵槽對齊置入。
- 2.馬達與減速機結合後，將馬達上4 根螺絲鎖緊。
- 3.使用T 型板手將入力軸束緊環鎖緊即可。

- 1.Place motor shaft key and reducer input shaft key way in a straight line, and insert motor shaft into reducer input shaft.
- 2.After connection of motor and reducer, tighten four screws into hex-socket cap screw holes.
- 3.Tighten the clamp of reducer input shaft by T-type spanner.

