


WF-HR 系列

型號開立：



段數 規格	一段減速比數	二段減速比數
WF42HR	3,4,5,6,7,8,10,14,16,20	15,25,30,35,40,50,70,80,100
WF60HR	3,4,5,6,7,8,10,14,16,20	15,25,30,35,40,50,60,70,80,100,120,140,160,200
WF90HR	3,4,5,6,7,8,10,14,16,20	15,25,30,35,40,50,60,70,80,100,120,140,160,200
WF115HR	3,4,5,6,7,8,10,14,16,20	15,25,30,35,40,50,60,70,80,100,120,140,160,200